



Technical Note: Detector Isolation

To isolate a detector, use the Remote Administration Tool to connect to the site and click 'Alarm Channels' in the left hand pane.


Select the detector in question from the drop-down box on the right.

Change the 'Member of Zone' setting to a zone that is never armed (out of the factory, 7 is a good choice here), see attached screen shot.

Click 'Apply' to activate.

To restore the detector to normal operation, repeat the steps above selecting the original zone (usually 1).

Technical Support Team



INTELLIGENT VIDEO LIMITED

REGISTERED ADDRESS

HAWKSTONE HOUSE, PORTLAND MEWS,
PORTLAND STREET, LEAMINGTON SPA, CV32 5HD

T: 01926 523040 | F: 01926 523041 | E: SALES@INTELLIGENTVIDEO.TV

WWW.INTELLIGENTVIDEO.TV

COMPANY NUMBER 7220067 | VAT NUMBER GB987674149